

Use of this gate on a fire escape window in New York City is illegal, a serious safety hazard and may result in a fine by the Department of Buildings.

WARNING

CHILD SAFETY WINDOW GUARD INSTALLATION INSTRUCTIONS

For Model no. 1123, 1124 and 1125 Window Guards for Windows 24" to 42" Wide
For Model no. 1123-S Window Guards for Windows 14-1/2" to 24-1/2" Wide
For Model no. 1123-L Window Guards for Windows 42" to 58" Wide

"NYC APPROVAL
#HDWG05-87-86"

WARNING: DO NOT INSTALL ON FIRE ESCAPE WINDOWS!

1. Install only in solid, non-rotting window tracks. Expand guard to fit tightly into outside window track.
2. Temporarily support guard in level position NO MORE THAN 4-1/2 inches from window sill to upper half of bottom bar. Mark location of top holes on each side. Remove guard and drill 5/32" dia. pilot holes 1" deep.
3. Re-position guard and drive #10 one way screws (provided by manufacturer) part way into jamb. Drill remaining holes and install all screws fully into window jamb.
4. Raise the inner window to NO MORE THAN 4-1/2" above the lower half of the top bar. On right hand side, position "L" shaped stop so as to limit the opening above the window guard to a maximum of 4-1/2" (see illustration). Mark and drill 5/32" dia pilot holes 1" deep. Repeat for the left side.
5. Secure each stop with two one way screws provided. Now the lower window sash (the inner window) should not be able to be raised more than 4-1/2" above the lower half of the top bar of the window guard.

NOTE: FOR USE ON DOUBLE HUNG WINDOWS ONLY-
SEE ILLUSTRATION

John Sterling Corporation , Richmond, Illinois U.S.A.

